

MDM FILE FORMAT AND LOAD PROCESS

PREPARED BY: AEMO MARKETS
VERSION: 1.~~10~~
EFFECTIVE DATE: 01 DECEMBER 2017
STATUS: DRAFT

Approved for distribution and use by:

APPROVED BY: PETER GEERS
TITLE: EXECUTIVE GENERAL MANAGER, MARKETS

DATE: ~~02DD /06MM /2017-YYYY~~

FOR INTERNAL USE ONLY

VERSION RELEASE HISTORY

Version	Effective Date	Summary of Changes
0.10	August 2009	Draft compilation of details from numerous sources and documents to form one complete detailed process document.
0.20	December 2009	Draft updated per first round responses.
1.0	February 2010	Update per draft determination responses, issued as Final.
1.0	1 December 2017	<u>Update to.....Updated to incorporate changes due to Power of Choice reforms and corrections.</u>

CONTENTS

1.	INTRODUCTION	4
1.1	Purpose and Scope	4
1.2	Definitions and Interpretation	4
1.3	Related Documents	4
2.	OVERVIEW	4
2.1	Outline of Metering Data Management (MDM)	4
2.2	Inputs Accepted by MDM	54
3.	PROCESS OF LOADING METERING DATA	5
3.1	Outline	5
3.2	Security	5
3.3	aseXML Message Format	6
3.4	Header Information	7
3.5	Transaction Information	8
3.6	CSV Consumption Data	89
3.7	CSVIntervalData	11
3.8	CSV Profile Data	14
3.9	Data Collection Type Codes	14
3.10	File Format	16
3.11	Data Load of Metering Data Files via the Browser (Interactive Upload)	1847
3.12	Data Load of Metering Data Files via the Batch Process	2928
4.	FILE VALIDATION	3029
4.1	Principles	3029
4.2	Validation of MDPVersionDT	3029
4.3	Validation of Start and End dates of reads (Including meta-reads)	3130
4.4	MSATS Data File Validations	3130
5.	MSATS ERROR CODES (MDM)	5049
5.1	Validation Failure Error Codes (MDM)	5049

1. INTRODUCTION

1.1 Purpose and Scope

This document specifies the Meter Data Management (MDM) Format to be used by MDPs for the provision of *metering data* to AEMO.

It also details the process for uploading the MDM files and the validations that occur when a file is submitted.

1.2 Definitions and Interpretation

The Retail Electricity Market Procedures – Glossary and Framework:

- (a) is incorporated into and forms part of this document; and
- (b) should be read with this document.

1.3 Related Documents

Title	Location
aseXML Schema	https://www.aemo.com.au/Electricity/National-Electricity-Market-NEM/IT-systems-and-change/aseXML_standards/aseXML-Schemas
Hints and Tips – CATS & NMI Discovery	https://www.aemo.com.au/Electricity/National-Electricity-Market-NEM/Retail-and-metering/Market-Settlement-and-Transfer-Solutions
CATS Procedures	https://www.aemo.com.au/Electricity/National-Electricity-Market-NEM/Retail-and-metering/Market-Settlement-and-Transfer-Solutions
MDM Procedures	https://www.aemo.com.au/Electricity/National-Electricity-Market-NEM/Retail-and-metering/Market-Settlement-and-Transfer-Solutions
Metrology Procedure: Part A	https://www.aemo.com.au/Electricity/National-Electricity-Market-NEM/Retail-and-metering
Metrology Procedure: Part B	https://www.aemo.com.au/Electricity/National-Electricity-Market-NEM/Retail-and-metering
NMI Procedure	https://www.aemo.com.au/Electricity/National-Electricity-Market-NEM/Retail-and-metering/Market-Settlement-and-Transfer-Solutions
Retail Electricity Market Procedures – Glossary and Framework	https://www.aemo.com.au/Electricity/National-Electricity-Market-NEM/Retail-and-metering/Glossary-and-Framework

2. OVERVIEW

2.1 Outline of Meter Data Management

2.1 MeterMetering Data Management (MDM)

~~MDM~~ is the ~~name given to the~~ centralised database of *metering data* ~~which is a component of AEMO's Market Settlement and Transfer Solution (within MSATS) system.~~ This database receives and holds meter data from non-interval and interval ~~metering~~ installations. Additionally, MDM provides storage for ~~data~~ and stores ~~profile information~~ ~~shapes provided from external Profile Preparation Service (PPS), as well as those~~ generated internally by MSATS.

~~Functionality within~~ MDM allows for storage of configuration data required to generate *profiles* that conform to the ~~NEM Metrology Procedure and estimate data that is metrology procedure and substitutes of~~ missing ~~for required time periods~~ *data*.

MDM is the source of data for ~~the Wholesale Settlement process initiated by AEMO in MSATS settlements.~~

2.2 Inputs Accepted by MDM

MDM accepts and stores ~~wholesale and contestable first and second tier energy~~ metering data as well as generator, and interconnector. MDM accepts interval and non-interval data that has been read, profiled, deemed (e.g. for unmetered supply), estimated or substituted for every active data stream. ~~This data is accepted in the NEM, which is submitted~~ in the form of a metering data notification transaction.

The metering data notification transaction is submitted to MSATS by ~~the Metering Data Providers (MDP)~~ MDPs in the form of a comma separated values-wrapped aseXML file. Details ~~regarding~~ the creation and submission of this file are ~~contained within~~ section 3 of this document. There are a number of validation requirements undertaken on the metering data notification transaction before the data file is accepted by MSATS.

Data is required for all ~~data streams defined~~ Datastreams in MSATS for any period of time where the ~~data stream status code~~ Datastream Status Code is set to 'A' (Active). MDM stores this data for every ~~data stream required~~ Datastream against a certain ~~connection point for settlement~~ settlements purposes. ~~This includes all tier 2 data, tier 1 data required for profile calculation, generator data, interconnector data, contestable customer and wholesale connection point data.~~

3. PROCESS OF LOADING METERING DATA

3.1 Outline

Once *NMI* and *connection point* information is set up in MSATS, ~~users specifically MDPs (or external data preparation services) have the ability to~~ MDPs can upload *metering data* into MSATS for ~~settlements~~ settlements processing. ~~This data, which~~ can be delivered to MSATS via the Browser (~~interactive loading~~) browser or via the Batch batch interface (~~direct loading~~).

- (a) ~~Interactive Loading (submitting files via the Browser)~~ – MDPs ~~have the ability to manually~~ can load *metering data* manually using the “Participant ~~Inbox~~” Inbox screen and the “~~Upload~~” Upload action. When MDPs click on the “~~Upload~~” Upload action, they are effectively placing the batch file into their ~~Inbox~~ Inbox directory on the file share on the AEMO network.

When using the Browser interface the File Upload Screen will be used to transfer a *metering data* file to the appropriate AEMO file directory (or ‘Participant ~~Inbox~~’ Inbox) for ~~settlements~~ settlements processing.

- (b) ~~Direct Loading Batch~~ – MDPs ~~also have the ability to~~ can place *metering data* files directly into their ‘Participant ~~Inbox~~’ Inbox directory on the AEMO network. This is the preferred option if an MDP has a large number of files to process.

3.2 Security

~~In order to~~ To upload *metering data* interactively (i.e. via the MSATS ~~Browser Interface~~) browser interface, the following rules must be adhered to:

- (a) The UserID identified in the SecurityContext element of the header must ~~be a user ID that belongs~~ belong to the ~~From~~ Participant ID.
- (b) The ~~User ID~~ UserID identified in the SecurityContext element in the XML message must be permitted to perform the batch transactions contained in the XML message (e.g. have been allocated a right that allows submission of MDM ~~Meter Data~~ metering data).
- (c) ~~If the file is being submitted via the browser, the user~~ The Participant User submitting the transaction must have a right that allows full access to the ‘Participant ~~Mailbox~~’ Mailbox entity.
- (d) ~~If the file is being submitted by the browser, the participant~~ The Participant ID ~~nominated in the From element~~ must match the logged-on ~~user’s participant~~ Participant User’s Participant ID.

3.3 aseXML Message Format

To import *metering data* into MSATS, the MDP systems must generate an XML-wrapped ~~.csv (Comma-Separated-Values)~~CSV file containing all relevant ~~metering~~Metering and ~~participant~~Participant information that conforms to the applicable aseXML ~~schema~~Schema.

This file must then be zipped and uploaded into MSATS using the [Browser](#)~~browser~~ interface, or by directly placing the file into the appropriate 'Participant ~~Inbox~~Inbox' on the AEMO fileshare.

The file itself will contain 3 main sections:

- (a) **Schema Information:** This section details the MSATS schema version information and should not be modified unless AEMO ~~notifies of an updated release through its change management process~~releases an update.
- (b) **Header Information:** This section contains information about the Participant ~~who is~~ submitting the file, its destination, and the type of transaction being submitted.
- (c) **Transaction Information:** This section contains all of the transaction-specific information, i.e. the actual *metering data* to be loaded.

This document has been developed using the current schema version, ~~whilst~~ Whilst all endeavours will be made to keep this document up to date with the schema changes, ~~this~~the document needs to be read in conjunction with the latest schema information available on the AEMO website.

The following [Figure 1](#) is an example of an aseXML file containing the CSV payload data. The file shows the structure of a transaction containing interval data. Note the examples in this document refer to schema version r25. please refer to the latest version available from the AEMO website.



FIGURE- 1 XML MESSAGE FORMAT

Figure 1 XML Message Format

3.4 Header Information

The ~~table~~ **Table 1** details the fields to be included in the 'Header' section of the XML-wrapped file. Take note of the 'Field Formats' to be used when creating the file. If a field entry is typed in the wrong case (i.e. not capitals) ~~then~~, the file may be rejected by MSATS.

Table 1 Table 1: HEADER INFORMATION

Field Name	Field Format	Example
<Description>	This is a free-text field that will allow the input of up to 30 characters. It is the description of the Participant (MDP) who is submitting the file. Can be upper or lower case	" Testing and Certification Australia MDP"MDP'
<From>	This is the The Participant ID of the userParticipant submitting the file (MDP). This ID, which must be typed in uppercase (capitals) . The field will allow entry of up to 8 characters.	TCAUSTM
<To>	This is the The AEMO Participant ID (i.e. the participant you are sending the file to) . Must, which must be typed in uppercase.	NEMMCO
<MessageID>	This is a unique, participant Participant-generated identifier for the file being sent. This ID, which can contain up to 50 characters.	"MDA1-MSG-2466453"2466453' "TCAUSTM017746632"TC AUSTM017746632'
<MessageDate>	Date and Time time identifier to be attached to the file. This must be in the following format: yyyy-mm-ddThh:mm:ss.sss+10:00	2001-12-31T08:59:11+10:00
<TransactionGroup>	This will identify Identifies the type of transaction being processed. When uploading metering data the transaction group will always be 'MDMT'. It is a 4- character string.	MDMT
<Priority>	This will identify Identifies the priority of the transaction. In turn, this priority will determine the order in which transactions are processed.	Low
<SecurityContext>	Security Context identifies to Identifies the 'User ID ID' of the userParticipant User submitting the file. The nominated user must have permission to submit this type of transaction.	USER1 JSMITH
<Market>		NEM

The ~~following~~ **Figure 2** is an example of the 'Header' section of an XML file:

```

<Header>
  <From>MDA1</From>
  <To>NEMMCO</To>
  <MessageID>MDA1-MSG-34567856</MessageID>
  <MessageDate>2009-10-31T13:20:10.100+10:00</MessageDate>
  <TransactionGroup>MDMT</TransactionGroup>
  <Priority>Low</Priority>
  <SecurityContext>zz023</SecurityContext>
  <Market>NEM</Market>
</Header>

```


FIGURE 2: XML HEADER EXAMPLE

Figure 2 XML Header Example

3.5 Transaction Information

The table below Table 2 details the fields to be included in the 'Transaction' section of the XML-wrapped file. Take note of the 'Field Formats' to be used when entering actual metering data

Table 2 Table 2: Transaction information

Field Name	Field Format	Example
<Transactionid>	This is a free-text field that will allow the input of up to 50 characters. It is a unique identifier assigned by the Participant to the transaction.	"MDA1-TNS-1887373"1887373'
<TransactionDate>	Date and Time identifier to be attached to the transaction itself. This must be in the format: yyyy-mm-ddThh:mm:ss.sss+10:00	2001-12-31T08:59:11+10:00
<MeterDataNotificationversion>	The schema version number that is currently in use.	"r25"r25'
CSV Data Type CSVDataType	<p>The participant has the choice of uploading Participant may upload interval metering data, consumption accumulation metering data or profile data. The prefix for each of these data types will be one of these:</p> <p>the below:</p> <ul style="list-style-type: none"> -CSVIntervalData -CSVConsumptionData -CSVProfileData (includes data for sample meters meter data) <p>CSV Data Types CSVDataTypes must be delivered in separate transactions. Optionally this field can contain the name attribute as per below:</p> <ul style="list-style-type: none"> -CSVIntervalData Name="Interval"='Interval' -CSVConsumptionData Name="Consumption"='Consumption' -CSVProfileData Name="Profile"='Profile' <p>Specific files captured for each of these CSV Data Types CSVDataTypes are detailed in the next section.</p>	<p><CSVConsumptionData></p> <p><CSVIntervalData></p> <p><CSVProfileData></p> <p>Optional Examples:</p> <p><CSVIntervalData Name="Interval">=Interval'</p> <p><CSVConsumptionData Name="Consumption">=Consumption'</p> <p><CSVProfileData Name="Profile">=Profile'</p> <p>></p>

3.6 CSV Consumption Data

CSVConsumptionData is used when loading metering data for data streams Datastreams listed in MSATS with a type of 'C' (consumption) which is for a basic/type 6 meter metering installation. The meter readings Meter Readings are not yet broken down into the 1/2 hourly intervals (as with CSVIntervalData).

Each component of the CSVConsumptionData listed in the below table Table 3 should be separated by a comma in the XML file.

For CSVConsumptionData delivered to AEMO (MSATS), the suffix detail must conform to the "National Metering Identifier Procedure (NMI)" for consumption metering data. The suffix identifier provided in the MDM CSVConsumptionData file must be identical to the datstream value entered into the MSATS CATS_NMI_DataStream table for the connection point identified by the NMI.

Table 133: Summary of Data Delivery

	DELIVERY TO ENTITLED PARTICIPANT e.g. LNSP, LR, FRMP	DELIVERY TO AEMO
Data Type	NMI data-stream Datastream (e.g. 11, 42) Deliver validated Validated metering data readings and consumption including any substitutions Substitutions and estimations Estimations.	NMI data-stream Datastream (e.g. 11, 42) Deliver validated consumption Validated metering data including any substitutions Substitutions and estimations Estimations.
File Format	'MDFF' Meter Data File Format:MDFF	'MDM' AEMO aseXML data file format.
Delivery Point	To the Registered Participants via B2B e-Hub inbox	To the Metering Data Provider's MDP's MSATS inbox

Field Name	Field Format	Example
NMI	The NMI (National Metering Identifier) , which identifies the <i>connection point</i> . It consists of 10 alphanumeric characters.	8166755454 VSSSS00001
Suffix	The NMI Suffix suffix. This is the suffix for the data-stream Datastream as defined in the MSATS Procedures.	11 42
MDPVersionDate	This is the date &and time stamp the participant Participant system has assigned to the data record. It is the date &and time the <i>metering data</i> was loaded into the MDP's system. The date & time and must be in the this format: yyyymmddhhmmss	20010714083045
FromDate	The first day of the reading Meter Reading period, in the this format of : Y yyyymmdd yyyymmdd Time is taken to be at 00:00 hours on the start day of the reading Meter Reading period.	20010501
ToDate	The last day of the reading period, in the this format of : yyyymmdd It is assumed to be taken at 23.59 hours. ~	20010731
Status	The quality flag of the metering data, which can be: A (Actual); E (Estimated); S (Substituted); or F (Final Substitutions) Refer metrology procedures Metrology Procedure: Part B for further detail on quality flags.	A, E, S, or F
Reading	This is the actual consumption value in kWh for the time period supplied (FromDate to the ToDate). In effect: Meter reading Reading at (ToDate – FromDate) = Consumption Reading consumption reading. All values must be inclusive of <i>meter</i> multipliers, therefore all consumption values and readings Meter Readings issued are multiplier adjusted.	1398.667

Below Figure 3 is an example of the Transaction Information of an aseXML file used in the loading of Consumption Data. Note the information components included next to the <CSVConsumptionData> section:

```
<?xml version="1.0" ?>
<ase:aseXML xmlns:ase="urn:aseXML:r25" xmlns:xsi="http://www.w3.org/2001/XMLSchema-
instance" xsi:schemaLocation="urn:aseXML:r25
http://www.aemo.com.au/aseXML/schemas/r25/aseXML_r25.xsd">
  <Header>
    <From>MDA1</From>
    <To>NEMMCO</To>
    <MessageID>MDA1-MSG-34567856</MessageID>
    <MessageDate>2009-10-31T13:20:10.100+10:00</MessageDate>
    <TransactionGroup>MDMT</TransactionGroup>
    <Priority>Low</Priority>
    <SecurityContext>zz023</SecurityContext>
    <Market>NEM</Market>
  </Header>
  <Transactions>
    <Transaction transactionID="MDA1-TNS-12343456" transactionDate="2009-10-
31T13:20:10.090+10:00">
      <MeterDataNotification version="r25">
        <CSVConsumptionData>NMI,Suffix,MDPVersionDate,FromDate,ToDate,Status,Reading
1234567890,A1,20091010143542,20090415,20090714,E,3.245
1234567890,A2,20091010143542,20090415,20090714,A,.446</CSVConsumptionData>
      </MeterDataNotification>
    </Transaction>
  </Transactions>
</ase:aseXML>
```

FIGURE 3: XML TRANSACTION INFORMATION

3.7 CSV Interval Data

```
<?xml version="1.0" ?>
<ase:aseXML xmlns:ase="urn:aseXML:r25" xmlns:xsi="http://www.w3.org/2001/XMLSchema-
instance" xsi:schemaLocation="urn:aseXML:r25
http://www.aemo.com.au/aseXML/schemas/r25/aseXML_r25.xsd">
  <Header>
    <From>MDA1</From>
    <To>NEMMCO</To>
    <MessageID>MDA1-MSG-34567856</MessageID>
    <MessageDate>2009-10-31T13:20:10.100+10:00</MessageDate>
    <TransactionGroup>MDMT</TransactionGroup>
    <Priority>Low</Priority>
    <SecurityContext>zz023</SecurityContext>
    <Market>NEM</Market>
  </Header>
  <Transactions>
    <Transaction transactionID="MDA1-TNS-12343456" transactionDate="2009-10-
31T13:20:10.090+10:00">
      <MeterDataNotification version="r25">
        <CSVConsumptionData>NMI,Suffix,MDPVersionDate,FromDate,ToDate,Status,Reading
1234567890,A1,20091010143542,20090415,20090714,E,3.245
1234567890,A2,20091010143542,20090415,20090714,A,.446</CSVConsumptionData>
      </MeterDataNotification>
    </Transaction>
  </Transactions>
</ase:aseXML>
```

Figure 3 XML Transaction Information

3.7 CSVIntervalData

CSVIntervalData is used when loading *metering data* for ~~data streams~~Datastreams listed in MSATS with a type of ~~"I"~~I (Interval) which is for ~~meter the following metering installations of:~~

- COMMS 1 to 4 (~~meter~~-type 1 through to 4);
- COMMS4D (whole current *metering* ~~installation~~installations that ~~meets~~meet the minimum services ~~specifications~~specification);
- COMMS4C (CT connected *metering* ~~installation~~installations that ~~meets~~meet the minimum services ~~specifications~~specification);
- MRAM (small customer *metering* ~~installation~~installations – Type 4A), VICAMI;
- MRIM (Manually Read Interval Meter or ~~meter~~-type 5);
- SAMPLE;
- PROF; and
- UMCP (unmetered supply or type 7).

The ~~meter readings~~Meter Readings will be broken down into 48 intervals of 30 minute-~~data~~.

Each component of the CSVIntervalData listed in ~~the following table (5)~~Table 3 should be separated by commas in the XML file.

For CSVIntervalData delivered to ~~AEMO (MSATS)~~AEMO (MSATS), the suffix detail must conform to AEMO's ~~"National Metering Identifier with the NMI"~~Procedure (NMI), for NMI for *interval metering data*. The Suffix value provided in the MDM CSVIntervalData file must be identical to the ~~datstream~~Datastream value entered into the MSATS CATS_NMI_DataStream table for the ~~connection point identified by the NMI~~NMI. The

suffix identifier for *interval metering data* (e.g. **N1**) is a ~~Netnet~~ value for the contributing import and export *interval metering data* flows for the ~~interval-meter~~Interval Meter concerned. The ~~Netnet~~ value for CSVIntervalData delivered to ~~AEMO~~ (MSATS), being as follows:

- Where the *metering data* is in sub-intervals of 30 minutes, the *metering data* must be aggregated to 30-minute intervals before delivery; and
- Where the *metering data* ~~collected~~ comprises separate export and import ~~data streams~~Datastreams, the respective export and import intervals must be aggregated E – B flows to provide the NET 'N' value. (Note: the net energy for ~~an-active~~a Generator is generally negative).

Table 3 ~~Table 5:~~ Summary of Data Delivery

	DELIVERY TO ENTITLED PARTICIPANT I.E. LNSP, NSP2, LR, FRMP	DELIVERY TO AEMO
Data Type	NMI data-stream <u>Datastream</u> (e.g. E1, B1) Deliver validated <u>Validated</u> <i>interval metering data</i> including any substitutions <u>Substitutions</u> and estimations <u>Estimations</u> .	NET value NMI data-stream <u>Datastream</u> (e.g. N1 = E1 – B1) Deliver validated <u>Validated</u> <i>metering data</i> including any substitutions <u>Substitutions</u> and estimations <u>Estimations</u> as net energy aggregated to 30 minutes.
File Format	'MDFF' Meter Data File Format:MDFF	'MDM' AEMO aseXML data file format.
Delivery Point	To the Registered Participants via <i>B2B e-Hub inbox</i>	To the Metering Data Provider's <u>MDP's</u> MSATS inbox

TABLE 6: CSV INTERVAL DATA**Table 4 CSVIntervalData**

Field Name	Field Format	Example
NMI	The NMI (National Metering Identifier), which identifies the <i>connection point</i> . It consists of 10 alphanumeric characters.	8105157686 8166755454 VSSSS00001
Suffix	The NMI Suffix suffix. This is the suffix for the data stream Datastream as defined in CATS (section 4.11.2).	N1 N2
MDPVersionDate	This is the date &and time stamp the participant Participant system assigned to the data record. It is the date &and time the <i>metering data</i> was loaded into the MDP's system: The date & time, which must be in the this format: yyyymmddhhmmss	20010714083045
SettlementDate	The date which the reading relates to ie: it is, the read Meter Reading date: This, which must be in the this format: Yyyymmdd	20010724
Status	Status of the Meter Reading. A status will need to be included for each 30- minute interval value (therefore there could be 48 'A' characters included for each data stream Datastream). Valid values are: A (Actual); E (Estimated); S (Substituted); or F (Final Substitutions) Refer metrology procedures Metrology Procedure: Part B for further detail on quality flags.	AAAAAAAAAAAAAAAAAAAA AAAAAAAAAAAAAAAAAAAA AAAAAAAAAAAA Or AAAAAASSSSSSSSAAAAA AAAAAAAAAAAAAAAAAAAAA AAAAFFFFFAA
Period 1 – 48	The consumption (in kWh) for each of the 30- minute interval reading Meter Reading periods, each . Each consumption record must be separated with a comma.	P1,P2,P3,P4,P5,P6,P7,P8,P9, P10,P11,P12,P13,P14,P15,P1 6,P17,P18,P19,P20,P21,P22, P23,P24,P25,P26,P27,P28,P2 9,P30,P31,P32,P33,P34,P35, P36,P37,P38,P39,P40,P41,P4 2,P43,P44,P45,P46,P47,P48,
DCTC ¹	Populate with the Meter Data Collection Type Code allocated for Metering Installation Type Code² associated with the metering data. Populate the Data Collection Type Code in accordance with section 3.9.	COMMS, COMMS4D , COMMS4C , MRIM, PROF, SAMPLE, MRAM VICAMI, UMCP.

~~Below~~Figure 4 is an example of the ~~Transaction Information~~transaction information for a XML file used in the loading of ~~Interval Data~~interval metering data. Note the information components included next to the <CSVIntervalData> section:

¹DCTC code to be an included part of the CSV Interval Data File from 25th November 2009 with release of version r25 schema, (part of the MSATS 46.74 build implementation). MSATS will accept MDM files complying with all schema versions up to 26 May 2010, after which MSATS will reject any MDM files not compliant to r25 schema version. Refer table 7- [Data Collection Type Code](#).

² Metering Installation Type Codes are defined in Section 4.12 of the MSATS Procedures: CATS

```

<?xml version="1.0"?>
<ase:aseXML xmlns:ase="urn:aseXML:r25" xmlns:xsi="http://www.w3.org/2001/XMLSchema-
instance" xsi:schemaLocation="urn:aseXML:r25
http://www.aemo.com.au/aseXML/schemas/r25/aseXML_r25.xsd">
  <Header>
    <From>MDA1</From>
    <To>NEMMCO</To>
    <MessageID>MDA1-MSG-34567856</MessageID>
    <MessageDate>2009-10-31T13:20:10.100+10:00</MessageDate>
    <TransactionGroup>MDMT</TransactionGroup>
    <Priority>Low</Priority>
    <SecurityContext>zz023</SecurityContext>
    <Market>NEM</Market>
  </Header>
  <Transactions>
    <Transaction transactionID="MDA1-TNS-12343456" transactionDate="2009-10-
31T13:20:10.090+10:00">
      <MeterDataNotification version="r25">
        <CSVIntervalData
Name="Interval">NMI,Suffix,MDPVersionDate,SettlementDate,Status,Period01,Period02,Period03,Pe
riod04,Period05,Period06,Period07,Period08,Period09,Period10,Period11,Period12,Period13,Period1
4,Period15,Period16,Period17,Period18,Period19,Period20,Period21,Period22,Period23,Period24,Pe
riod25,Period26,Period27,Period28,Period29,Period30,Period31,Period32,Period33,Period34,Period3
5,Period36,Period37,Period38,Period39,Period40,Period41,Period42,Period43,Period44,Period45,Pe
riod46,Period47,Period48,DCTC
1234567890,A1,20091010143542,20090415,EEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEE
EEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEE
3.422,3.825,4.163,3.456,3.979,3.401,3.567,3.556,3.948,3.732,3.743,3.898,3.859,3.
899,3.749,3.396,3.685,3.827,3.448,3.562,3.949,3.465,3.462,3.618,3.699,3.838,3.68,4.158,3.705,4.14
9,3.633,3.514,4.022,4.077,3.916,3.501,3.429,3.796,3.645,3.695,4.079,3.36,3.962,3.432,3.852,3.965,
3.412, 4.002,COMMS</CSVIntervalData>
      </MeterDataNotification>
    </Transaction>
  </Transactions>
</ase:aseXML>

```

Figure 4 ~~Figure 4~~ **FIGURE 4:** XML Transaction information

3.8 CSV Profile Data

~~Please refer to Section 3.7 – CSV Interval Data for the format of profile data. The only difference relates to the CSV Data type CSVProfileData differs from CSVIntervalData in the aseXML transaction information, which reads <CSVProfileData>, rather than <CSVIntervalData> see section 3.5, table 2. CSVProfileData. CSVProfileData is currently used for sample meters (meter installation codes Metering Installation Type Codes of Sample or COMMS4) to supply profile data for the control load Controlled Load profile calculation process in the relevant jurisdictions Jurisdictions.~~

3.9 Data Collection Type Codes

~~The Data Collection Type Codes (DCTC) used within the MDM interval metering data file must be the DCTC that has been allocated for referred to in Table 4 are the Metering Installation Type Code³ associated with the metering data. in all but one case. The table below provides only exception is where a list of applicable DCTCs and corresponding Metering Installation Type Codes: Code for a metering installation is a COMMS1, COMMS2, COMMS3 or COMMS4. The equivalent DCTC is COMMS. See table 5.~~

³ Metering Installation Type Codes are defined in Section 4.12 of the MSATS Procedures: CATS

Table 5 DCTC Code – Metering Installation Type Code Mapping

<u>DCTC Code</u>	<u>Metering Installation Type Code</u>
<u>COMMS</u>	<u>COMMS1, COMMS2, COMMS3, COMMS4</u>
<u>COMMS4D</u>	<u>COMMS4D</u>
<u>COMMS4C</u>	<u>COMMS4C</u>
<u>MRIM</u>	<u>MRIM</u>
<u>PROF</u>	<u>PROF</u>
<u>SAMPLE</u>	<u>SAMPLE</u>
<u>MRAM</u>	<u>MRAM</u>
<u>VICAMI</u>	<u>VICAMI</u>
<u>UMCP</u>	<u>UMCP</u>

The inclusion of the DCTC field within the MDM interval metering data files delivered to AEMO becomes a requirement from 25 November 2009 with the release of schema version r25. The inclusion of the DCTC field to be as follows:

The DCTC code shall ~~Rules governing the use DCTC codes are:~~

- (a) It must be a maximum of eight characters in length.
- (b) ~~Additional DCTC codes may be added to this list in the future to support other market developments.~~
- (c) ~~AEMO system will accept MDM interval metering data files compliant to all MDM schema file versions for a period of six months post the implementation of schema version r25 as part of MSATS Build 46.74 scheduled for 25 November 2009.~~
- (d) ~~After the 26 May 2010, all MDM interval metering files delivered to AEMO must comply with the required r25 schema syntax.~~
- ~~(e)~~(b) MSATS will not validate the DCTC ~~field~~code against previous file history for the NMI.

TABLE 7: SCHEMA VERSION FIELD REQUIREMENTS

~~Table 4~~**Table 6** ~~For the period up to 26 May 2010, valid combinations~~Valid Combinations of Schema and Transaction Versions ~~are:~~

<u>Schema Version</u>	<u>Transaction Version</u>	<u>Interval</u>	<u>Profile</u>	<u>Consumption</u>
r7	r4	no DCTC field required	no DCTC field required	no DCTC field required
r9	r9	no DCTC field required	no DCTC field required	no DCTC field required
r10	r9	no DCTC field required	no DCTC field required	no DCTC field required
r22	r19	no DCTC field required	no DCTC field required	no DCTC field required
r25	r25	DCTC field optional	DCTC field optional	no DCTC field required

~~For the period from 26 May 2010 onwards, valid combinations of Schema and Transaction Versions are:~~

Schema Version	Transaction Version	Interval	Profile	Consumption
r25	r25	DCTC field required	DCTC field required	no DCTC field required

```
<MeterDataNotification version="r25">
  <CSVIntervalData
    Name="Interval">NMI,Suffix,MDPVersionDate,SettlementDate,Status,Period01,Period02,Period03,Pe
    riod04,Period05,Period06,Period07,Period08,Period09,Period10,Period11,Period12,Period13,Period1
    4,Period15,Period16,Period17,Period18,Period19,Period20,Period21,Period22,Period23,Period24,Pe
    riod25,Period26,Period27,Period28,Period29,Period30,Period31,Period32,Period33,Period34,Period3
    5,Period36,Period37,Period38,Period39,Period40,Period41,Period42,Period43,Period44,Period45,Pe
    riod46,Period47,Period48,DCTC
    1234567890,A1,20091010143542,20090415,EEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEE
    AAAAAAAAAAAAAA,3.422,3.825,4.163,3.456,3.979,3.401,3.567,3.556,3.948,3.732,3.743,3.898,3.859,3.
    899,3.749,3.396,3.685,3.827,3.448,3.562,3.949,3.465,3.462,3.618,3.699,3.838,3.68,4.158,3.705,4.14
    9,3.633,3.514,4.022,4.077,3.916,3.501,3.429,3.796,3.645,3.695,4.079,3.36,3.962,3.432,3.852,3.965,
    3.412. 4.002,COMMS</CSVIntervalData>
```

FIGURE 5:

```
<MeterDataNotification version="r25">
  <CSVIntervalData
Name="Interval">NMI,Suffix,MDPVersionDate,SettlementDate,Status,Period01,Period02,Period03,Pe
riod04,Period05,Period06,Period07,Period08,Period09,Period10,Period11,Period12,Period13,Period1
4,Period15,Period16,Period17,Period18,Period19,Period20,Period21,Period22,Period23,Period24,Pe
riod25,Period26,Period27,Period28,Period29,Period30,Period31,Period32,Period33,Period34,Period3
5,Period36,Period37,Period38,Period39,Period40,Period41,Period42,Period43,Period44,Period45,Pe
riod46,Period47,Period48,DCTC
1234567890,A1,20091010143542,20090415,EEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEE
AAAAAAAAAAAA,3.422,3.825,4.163,3.456,3.979,3.401,3.567,3.556,3.948,3.732,3.743,3.898,3.859,3.
899,3.749,3.396,3.685,3.827,3.448,3.562,3.949,3.465,3.462,3.618,3.699,3.838,3.68,4.158,3.705,4.14
9,3.633,3.514,4.022,4.077,3.916,3.501,3.429,3.796,3.645,3.695,4.079,3.36,3.962,3.432,3.852,3.965,
3.412, 4.002,COMMS</CSVIntervalData>
```

Figure 5 Example (MDM) Meter Metering Data File with DCTC

3.10 File Format

Once all the information in the aseXML file is correct ~~the file,~~ it must be saved and converted into a .zip file. The .zip file must have a name that conforms to the following standard.

~~Table 8: file format~~

Table 7 Zip File Format

Field Name	Field Format	Example
Transaction Group	In the case of MDM Transactions <u>transactions</u> , the transaction group will be “mdmt”-“mdmt”.	4 Alphanumeric
Priority	h = High m = Medium l = Low Messages within each priority group are processed in last modified order. The priority for meter <u>metering</u> data transactions is l.	1 Character
Unique ID	Unique ID that can be generated by Participant systems. The first part may be the Participant ID.	30 Alphanumeric characters

Field Name	Field Format	Example
Extension	<p>The Data file (XML-wrapped CSV file) should be saved as .zip file.</p> <p>The .zip extension is the only extension recognised by MSATS.</p> <p>Once recognised the batchhandler<u>batch handler</u> will pick up and process the file.</p>	3 characters

An example of a filename (once zipped) is shown below:




FIGURE 6: FILENAME EXAMPLE




Figure 6 Filename Example

3.11 Data Load of Metering Data Files via the Browser (Interactive Upload)

Once set up with an appropriate MSATS login ID and password, ~~thean~~ MDP participant will ~~then~~ be able to import *metering data* using the 'File ~~Upload~~Upload' screen (or 'Participant ~~Inbox~~Inbox').

~~MDPs that have a limited amount of files to process can elect to use the Browser interface; however it is highly recommended that larger MDPs implement automated batch interface processes.~~ The browser interface should also be considered as an emergency option for delivery of *metering data* ~~inif~~ the ~~event of a~~ batch processing system ~~failure~~fails.

The browser interface allows an MDP to interactively manage ~~theirits~~ file transfer activities. MDPs will be able to view, upload, and delete files from their 'Participant ~~Inbox~~Inbox', and read any acknowledgments from their 'Participant ~~Outbox~~Outbox'.

Important Note:


~~In order for an MDP to To~~ use the ~~Browser~~browser interface to deliver *metering data* ~~into theto~~ MSATS database, ~~they~~, MDPs must be set up with the following access rights in the system:

- Active Participant ID
- Full access to the 'Participant ~~Mailbox~~Mailbox' entity (~~Inbox, Outbox~~('Inbox', 'Outbox' and ~~Archive~~Archive')
- Active User ID & ~~Password~~password
- Ensure that the UserID identified in the SecurityContext has been assigned a ~~Rightright~~ that will allow access to the appropriate MSATS batch procedures.

To import *metering data* interactively using the ~~Browser Interface~~browser interface:

- Log onto the MSATS ~~Browser~~browser with appropriate access rights.

2. From the 'Data Load ~~Import~~Import' menu select the 'Participant ~~Inbox submenu~~Inbox' sub-menu option on the MSATS menu bar.



The following screen will display in the main window:-

Participant Inbox - List		Participant ID:	TCAUSTM
		Participant Name:	Testing and Certification Austral MDP
<input type="button" value="Delete Selected"/> <input type="button" value="Select All"/> <input type="button" value="De-select All"/>			
Inbox Contents		Upload	
File Name	Last Modified	File Size	
<input type="button" value="Delete Selected"/> <input type="button" value="Select All"/> <input type="button" value="De-select All"/>			

- To import data into MSATS click on the Upload hyperlink above the File Size column.


<u>Upload</u>
<u>File Size</u>

- The following screen will display in the main window.

File Upload		Participant ID:	TCAUSTM
		Participant Name:	Testing and Certification Austral MDP
File to Upload (*):	<input type="text"/> <input type="button" value="Browse..."/>		
<input type="button" value="Submit"/>			

Note: File Upload

- Using this screen the MDP ~~will have the ability to~~ can select one of their data files to import into ~~the~~ MSATS ~~database~~.
 - The ~~user~~ MDP can either enter the path to the file directly in the text field, or use the ~~BROWSE~~ Browse button to open the standard navigator type interface.
- To select a file to import click on the Browse... button. A ~~CHOOSE FILE~~ Choose File window should now appear.
 - The ~~CHOOSE FILE~~ Choose File window will allow the user to browse through their local network to select the relevant file to import.

**Note:**

- (a) Once you have found the file you wish to import, highlight it in the window and click on the **Open** button. (Alternatively you can double-click on the file to attach.)
 - (b) Ensure you select the zipped version of your data file. The MSATS batch handlers that **pick up** and process these files will only identify those files with a '.zip' extension.
7. The **'File Upload'** screen will now appear, and the **'File to Upload'** field will be populated with the location details of the file you just selected.

File Upload	Participant ID:	TCAUSTM
	Participant Name:	Testing and Certification Austral MDP
File to Upload (*):	C:\NEMMCO\MSATS Dc Browse...	
Submit		

8. To import the file click on the **Submit** button. MSATS will now attempt to upload the file.

Note:

- (a) The time taken to upload a file will vary depending on the size of the file, and the speed of the connection.
- (b) When uploading via the **Browser** interface the size of the file to be uploaded (before compression into a .zip file) is limited to a maximum of 1MB.
- (c) The action of clicking **Submit** will place the .zip file into the **'Participant Inbox'** directory.

- (d) MSATS will then process the .zip file and create an acknowledgment file in the Participant Outbox.
9. During this initial upload, MSATS will perform ~~4sta~~ first level validation on the aseXML file. MSATS will ensure that the following information is correct:
- (a) ~~the~~The UserID nominated in the SecurityContext element of the message is permitted to perform the type of batch transaction being submitted (MDM ~~Meter Data~~ metering data batch entity).
 - (b) ~~the~~The XML is well formed (i.e. that it meets the rules ~~defined~~ for writing XML).
 - (c) ~~the~~The file is valid according to the rules specified in the aseXML schema.
 - (d) ~~the~~The schema and transaction versions are supported by MSATS.
 - (e) ~~the~~The TransactionID has not previously been submitted.
 - (f) ~~the~~The file size does not exceed the 1MB unzipped limit.
10. After completing the first level validation, MSATS will display the submitted information and the results of the validation in the form of an acknowledgement or .ack file.
- Note:
- (a) If the validation can be completed immediately, the message is displayed on the screen.
 - (b) If MSATS ~~is able to~~ can load the data in the message, the acknowledgment screen will display an XML transaction that acknowledges the status of the message as a whole and of the transaction in the message.
 - (c) An example of the acknowledgement is as follows:

The file "mdmtl_tcaustm_8.zip" has been successfully processed.
Please check your Outbox for results.

The "mdmtl_tcaustm_8.ack":

```

<TransactionGroup>MDMT</TransactionGroup>
<Priority>Low</Priority>
<SecurityContext>NEMMCO</SecurityContext>
</Header>
<Acknowledgements>
  <MessageAcknowledgement initiatingMessageID="TCA-LOAD-8000"
receiptDate="2004-06-29T19:54:23+10:00" receiptID="MDMT-61502" status="Accept"/>
  <TransactionAcknowledgement initiatingTransactionID="TCA-TNS-ABC0-
8000_sw1" receiptDate="2004-06-29T19:54:23+10:00" receiptID="MDMT-61502" status="Accept"/>
</Acknowledgements>
</ase:aseXML>
  
```

Return to "Participant Inbox - List" screen.

The file "mdmtl_tcaustm_8.zip" has been successfully processed.
Please check your Outbox for results.

The "mdmtl_tcaustm_8.ack":

```

<TransactionGroup>MDMT</TransactionGroup>
<Priority>Low</Priority>
<SecurityContext>NEMMCO</SecurityContext>
</Header>
<Acknowledgements>
  <MessageAcknowledgement initiatingMessageID="TCA-LOAD-8000"
receiptDate="2004-06-29T19:54:23+10:00" receiptID="MDMT-61502" status="Accept"/>
  <TransactionAcknowledgement initiatingTransactionID="TCA-TNS-ABC0-
8000_sw1" receiptDate="2004-06-29T19:54:23+10:00" receiptID="MDMT-61502" status="Accept"/>
</Acknowledgements>
</ase:aseXML>
  
```

Return to "Participant Inbox - List" screen.

Message
acknowledgement

Transaction
acknowledgement

- (d) That there is both a message acknowledgement and a transaction acknowledgement.
- (e) There is only ever one message acknowledgement per batch file.

- (f) Depending on the number of transactions in the message there could be multiple transaction acknowledgements.
 - (g) For this transaction group, there will only be one transaction in a message, but the message can consist of many rows.
 - (h) A transaction can contain consumption or interval .csv data, but not both.
 - (i) Messages and transactions that pass the validation have a status of 'Accept'. Messages and transactions that fail the validations have a status of 'Reject'.
 - (j) It is possible ~~that for~~ the message ~~may to~~ be accepted but not the transaction. This would be the case if, for example, the message is well formed, the header details are correct but the nominated user did not have the rights to perform this specific transaction within the Transactions element
 - (k) Once the .zip file message (data file) has been uploaded it will remain in the 'Participant ~~InboxInbox~~' until MSATS has processed it. Once processed, an .ack file will be placed in the corresponding 'Participant ~~OutboxOutbox~~'. Once the .ack file has been read and processed by the MDP's system, the original .zip file will need to be deleted from the 'Participant ~~InboxInbox~~' following which MSATS will delete the .ack file.
11. If *metering data* that was successfully loaded from the .xml file (i.e. the transaction had an ~~Accept~~ 'Accept' message), the .csv data will undergo a ~~2ndsecond~~ level functional validation. Once this ~~2nd level processing~~ is complete MSATS will generate a message containing a 'Meter Data ~~ResponseResponse~~' transaction and place it into the MDP's 'Participant ~~OutboxOutbox~~' in a .zip file. The second level validation consists of the following:
- (a) the MDP-~~(Participant ID)~~ submitting the data is correct based on the MDP of record in MSATS for all *NMIs* and all intervals and periods of *metering data* submitted;
 - (b) the *NMI* ~~data stream~~ Datastream, as identified by the suffix has a ~~Data stream~~ Datastream Status Code of 'A' (Active) for the period of data provided; and
 - ~~(b)(c)~~ that the start and end dates of the data record being validated do not overlap any existing records in such a way that the new record would replace only part of the period covered by an existing record. (See section 3 on validation).

Note:

If a consumption data file contains multiple ~~reads~~ Meter Readings for the same *NMI* and suffix they will be validated to see if they would form a 'virtual single read' or 'meta-read'. The file is checked to see if all data periods considered together will represent a continuous period of time – i.e. one ~~read's~~ Meter Reading's end date must be the day before the next one's start date). Multiple ~~reads~~ Meter Readings that form a 'meta-read' are, for the remainder of the validations, treated as a single ~~read~~ Meter Reading. If the 'meta-read' fails any of the other validations, the group of ~~reads~~ Meter Readings are not loaded. Each of the individual ~~reads~~ Meter Readings, however, are then validated independently and loaded if they pass the validation. If the 'meta-read' passes all of the other validations, ~~then~~ each of the individual ~~reads~~ Meter Readings that make the virtual ~~read~~ Meter Reading will be loaded as separate records.

12. Navigate to the 'Participant Outbox – ~~ListList~~' screen.

There is one 'Meter Data ~~ResponseResponse~~' in the form of an .xml message in a .zip file, for each 'Meter Data ~~NotificationNotification~~' transaction in the original file. Given that ~~currently~~ MSATS only allows one 'Meter Data ~~NotificationNotification~~' transaction per file, this means that there will be one 'Meter Data ~~ResponseResponse~~' file for each file that was loaded. Each response file will appear in the Participant Outbox. The filename of the response appears in the format of:


- (a) Transaction Group & Priority = mdmtl

- (b) Underscore = _
- (c) User ID = <participantid>batch
- (d) Underscore = _
- (e) Unique Message ID = e.g. 22899696


<input type="checkbox"/>	mdmtm_tcaustmbatch_22926493.zip	Tue Jun 29 19:39:40 EST 2004	12550
<input type="checkbox"/>	mdmtm_tcaustmbatch_22926497.zip	Tue Jun 29 19:39:40 EST 2004	13297
<input type="checkbox"/>	mdmtm_tcaustmbatch_22926498.zip	Tue Jun 29 19:39:41 EST 2004	13302
<input type="checkbox"/>	mdmtm_trainmdm_22926533.zip	Tue Jun 29 19:41:16 EST 2004	748
<input type="checkbox"/>	mdmtm_trainmdm_22961536.zip	Tue Jun 29 22:20:16 EST 2004	660

Participants can then click on the 'File **NameName**' hyperlink to view the ~~meter data response~~ 'Meter Data Response' file, which contains details of ~~2ndsecond~~ level processing.

13. To view the 'Meter Data ~~ResponseResponse~~' message, click on the 'File **NameName**' hyperlink. You may then be asked if you wish to "Open the ~~file~~file" or "Save it to your ~~computer~~computer".



Select the option that best suits the needs of your organisation. (This message may or may not appear depending on your Windows settings for opening files with a .zip extension.)

14. You should save the file if you wish to keep a permanent copy. However, you may want to open it first, the process which is described in these steps. Click the  button to open the .zip file.

You will now be able to see the .xml file inside the .zip file.

15. Once the .zip file is opened (either immediately or later after you've downloaded it), you then need to open the .xml file contained in the .zip file so you can read its contents.

Depending on the application you use to open compressed files and your Windows settings, either single-click the file name (if it's underlined) or double-click the file name to open it.

The file will be opened in whatever application you have associated with .xml files. In the examples in this documentation, it is Internet Explorer.

Following Figure 7 is an example of a 'Meter Data ~~Response~~Response' message:

```
<?xml version="1.0" ?>
<ase:aseXML xmlns:ase="urn:aseXML:r25" xmlns:xsi="http://www.w3.org/2001/XMLSchema-
instance" xsi:schemaLocation="urn:aseXML:r25
http://www.aemo.com.au/aseXML/schemas/r25/aseXML_r25.xsd">
  <Header>
    <From>MDA1</From>
    <To>NEMMCO</To>
    <MessageID>MDA1-MSG-34567856</MessageID>
    <MessageDate>2009-10-31T13:20:10.100+10:00</MessageDate>
    <TransactionGroup>MDMT</TransactionGroup>
    <Priority>Medium</Priority>
    <SecurityContext>zz023</SecurityContext>
    <Market>NEM</Market>
  </Header>
  <Transactions>
    <Transaction transactionID="MDMT-TNS-12343456" transactionDate="2009-10-
31T13:20:10.090+10:00"
    initiatingTransactionID="MDA1-TNS-12343456">
      <MeterDataResponse version="r6">
        <ActivityID>67856</ActivityID>
        <AcceptedCount>1</AcceptedCount>
        <LoadDate>2009-11-29T19:52:50+10:00</LoadDate>
      </MeterDataResponse>
    </Transaction>
  </Transactions>
</ase:aseXML>
```

FIGURE 7: XML RESPONSE MESSAGE FORMAT

Figure 7 XML Response Message Format

Note: ~~version="r6"~~version' r6' is correct for this response report under the r25 schema

The ~~ActivityID~~'ActivityID' is a unique ID assigned by MSATS ~~which is~~ used for internal MDM processing.

The numeric part of the ~~MessageID~~'MessageID' and the ~~TransactionID~~'TransactionID' matches the numeric part of the .zip file name.

The end of the first line in the ~~Transactions~~'Transactions' element contains the initiating ~~TransactionID~~.

'TransactionID'. This is the ~~TransactionID~~'TransactionID' that was supplied by the MDP in the ~~MeterDataNotification~~'MeterDataNotification' transaction. This identifier is the key piece of information for identifying which original transaction this response refers to.

The value in the ~~AcceptedCount~~'AcceptedCount' element is the number of rows that were accepted (i.e. loaded) and ~~LoadDate~~'LoadDate' is the date and time MSATS loaded the accepted data.

The code within the ~~Event~~'Event' element(s) contains the outcome of the validations.

A code of '0' means that all of the data was successfully loaded.

If any errors are encountered, ~~then~~ summary information about each failed ~~read~~Meter Reading is displayed in an ~~Event~~'Event' element (i.e. one ~~Event~~'Event' element for each failed ~~read~~Meter Reading). Thus, the ~~AcceptedCount~~'AcceptedCount' plus the number of error events should equal the number of reads submitted.

In the example that follows, there are two rejected reads.

```

<Event severity="Error"'Error'>
  <Code>1089</Code>
  <KeyInfo>2</KeyInfo>
  <Context>RIP0000510,11,26-SEP-02,30-DEC-02 11:22:39</Context>
</Event>
<Event severity="Error"'Error'>
  <Code>1099</Code>
  <KeyInfo>3</KeyInfo>
  <Context>RIP0000510,11,04-OCT-02,10-OCT-02 11:22:39</Context>
</Event>
</MeterDataResponse>
</Transaction>
</Transactions>
</ase:aseXML>

```

The four digit code in the ~~Code~~'Code' element is an error code. Error code 1089 represents the error 'There is a record in the system that overlaps this record with a 'Version ~~DateDate~~'DateDate' that is after or equal to the 'Version ~~DateDate~~'DateDate' of this record.' Error code 1099 represents the error 'Read failed as part of Meta-read'.

A full list of error codes and descriptions are available ~~from~~in MSATS. The list of error codes is found under 'Administration/Codes Maintenance/Error ~~CodesCodes~~'CodesCodes' or via a C1 report the on ~~Error CodesCodes~~'Error CodesCodes' table.

The ~~KeyInfo~~'KeyInfo' element contains the row number. Note that the first row number that contains metering data is row 2. Row 1 contains the column headings.

The ~~Context~~'Context' element contains each of the following, separated by commas.

- (a) NMI
- ~~(b) Data stream~~
- ~~(b) Datastream~~
- (c) Start Date
- (d) MDP Version Date Time.

3.12 Data Load of Metering Data Files via the Batch Process (~~Direct Loading~~)

MDPs ~~will~~can also ~~have the ability to~~ deliver data files into MSATS using the batch process. This would involve placing the aseXML data file directly into the '~~Participant Inbox~~Inbox' directory ~~on~~at the appropriate AEMO network location.

The information to be included in the aseXML file is identical to that ~~which is~~ detailed in section 3.3. at the beginning of section 2—Process of Loading Metering Data.3.

To load data directly:

1. Create the aseXML *metering data* file and save it as a zip file (ensure the file is saved according to AEMO aseXML standards and that the file is under 1MB before it is compressed into a .zip file~~)).~~.
2. The file should be loaded into the appropriate '~~Participant Inbox~~Inbox' with an extension of .tmp (this is to ensure the system does not attempt to process a partially loaded file).
3. Once loaded rename the file to have its correct extension (i.e. change the name from XXX.tmp to ~~—~~XXX.zip).
4. The ~~MSATS~~ batch handlers will detect this .zip file in the INBOX directory and perform ~~1st Level a first level~~ validation.
 - (a) ~~—~~MSATS will produce an acknowledgment file (.ack) and ~~will~~ place it in the ~~OUTBOX~~ 'Outbox' directory.
 - (b) ~~—~~This .ack file will contain the results of ~~1st Level~~the first level validation.
 - (c) ~~—~~Having received the .ack file, you need to delete the .zip file from your ~~Inbox~~'Inbox'.
 - (d) ~~—~~MSATS will detect that the .zip file has been deleted and delete the .ack file from the ~~Outbox~~'Outbox'.
5. Assuming that the acknowledgment indicated that the transaction passed the ~~1st~~first level validations, the data loaded from the file will now undergo ~~2nd~~second level validation processing. On completion of ~~2nd~~second level validation processing, a message containing a '~~Meter Data Response~~Response' transaction (in a .zip file) will appear in the MDP's '~~Participant Outbox~~Outbox' directory.
6. This file is identical to the one you would receive if you submitted the file containing the ~~meter~~metering data using the ~~Browser~~browser. You can either:
 - (a) ~~—~~Follow the steps for ~~"Data Load of Metering Data Files via the Browser (Interactive Upload)"~~Browser, beginning at step 12 to view and acknowledge the message using the ~~Browser~~browser; or
 - (b) Copy the file from the '~~Participant Outbox~~Outbox' folder to your own system and then write an .ack file in your '~~Participant Inbox~~Inbox' folder to acknowledge its receipt. MSATS will then delete the original.

4. FILE VALIDATION

4.1 Principles

Validation of single ~~reads~~Meter Readings is based on alignment with overlapping start and end dates of existing records as well as on the MDP ~~Version~~version date and time. Exceptions are where the existing overlapping ~~read~~Meter Reading is ~~a forward estimate~~an Estimate.

Initial validations undertaken in CATS (before it is accepted by the MDMs):

- (a) ~~Data streams~~Datastreams are active. For non-~~interval~~interval ~~Datastreams~~Datastreams, this includes for the duration of the ~~read~~Meter Readings.
- (b) The MDP must be the '~~current/active~~Current' MDP on the '~~To Date~~Date' for a non-~~interval~~interval ~~read~~Meter Reading and the '~~Read Date~~Date' if it is interval/~~profile~~profile data.
- (~~b~~)(c) The TNI is assigned to a ~~profile area~~Profile Area.
- (~~c~~)(d) There are no duplicate ~~reads~~Meter Readings within the input file (NMI, ~~data stream~~Datastream, start date, or ~~read~~Meter Reading date if interval date) If there is a duplicate record the first record is accepted and following records are rejected.
- (~~d~~)(e) Validation of start (1000 days from submit date) and end date (1000 days from submit date) for a non-~~interval~~interval ~~read~~Meter Reading. For an interval/~~profile~~profile ~~read~~Meter Reading the ~~read~~ date must be no more than 1000 days before the submit date or 1000 days into the future.

4.2 Validation of MDPVersionDT

For ~~Interval~~interval and non-interval ~~reads~~Meter Readings:

- (a) The load of any new ~~meter~~metering data records into MSATS, which are to replace existing ~~meter~~metering data records for a NMI/~~datastream~~Datastream, will be validated for ~~MDPVersionDT~~'MDPVersionDT' where the MDP ~~participant~~Participant ID is the same for both ~~reads~~Meter Readings supplied. The ~~MDPVersionDT~~'MDPVersionDT' for the new data record must be greater than, the ~~MDPVersionDT~~'MDPVersionDT' of the existing record in MDM.
- (b) The load of new data records into MSATS ~~which are~~ to replace existing ~~meter~~metering data records for a NMI/~~datastream~~Datastream where the existing data record was supplied by a different MDP ~~participant~~Participant ID will be accepted. No validation is undertaken against ~~MDPVersionDT~~'MDPVersionDT' in this situation.

A separate error code exists ~~for the situation~~ where the ~~MDPVersionDT~~'MDPVersionDT' is the same – to distinguish from those where the ~~MDPVersionDT~~'MDPVersionDT' is less than the record existing in MDM.

For '~~meta-reads~~reads', the maximum ~~MDPVersionDT~~'MDPVersionDT' of the '~~meta-read~~read' is used (i.e. the maximum of the ~~MDPVersionDT~~'MDPVersionDT' of all the individual records that make up the '~~meta-read~~read'). This is then compared with the maximum ~~MDPVersionDT~~'MDPVersionDT' of all of the overlapping existing records in MDM in the '~~meta-read~~read' start and end date range. This could allow some of the rows in the '~~meta-read~~read' to replace records in MDM that have a later ~~MDPVersionDT~~'MDPVersionDT', but as the incoming ~~meter~~metering data file is created from the ~~MDP's~~MDP's metering ~~data base, then database~~, all the records in the incoming file should be the latest, if one or more of them has a later ~~MDPVersionDT~~'MDPVersionDT' than that exists in MDM.

4.3 Validation of Start and End dates of reads (Including meta-reads)

The process of the validation of start and end dates of ~~basic meter read~~ Accumulation Meter Reading records in a single transaction will be as follows:

- (a) Sort the readsMeter Readings in start date order.
- (b) Create a 'meta-~~readread~~', which consist of all records that align with each other, and use the start date and the end date of the 'meta-~~readread~~' for validation (e.g. two readsMeter Readings – one 1/3 to 31/3, one 1/4 to 30/4, meta-read 1/3 to 30/4) (Overlapped new readsMeter Readings will not form 'meta-~~readsreads~~' since their dates do not align and will be validated as single readsMeter Readings, each in turn).
- (c) The start and end dates of the 'meta-~~readread~~' (which may be a single readMeter Reading) must either align with existing valid current readsMeter Readings or fall in periods where there is no current readMeter Reading – this allows the new 'meta-~~readread~~' to fill in gaps in readsMeter Readings.
- ~~Forward~~
- (d) Estimate Test: Existing ~~forward-estimates~~ Estimates (read type flag = 'E') are not considered in the start and end date validation process of new readsMeter Readings (regardless of whether the new readMeter Reading is ~~a forward estimate or not~~ an Estimated Meter Reading).
- ~~Data stream~~
- (e) Datastream Inactive Test: Existing readsMeter Readings that span periods that the data stream Datastream is now inactive (due to retrospective changes) are also not considered in the start and end date validation process of new readsMeter Readings (these existing readsMeter Readings are now effectively invalid due to the readMeter Reading spanning an inactive period).
- (f) If a 'meta-~~readread~~' fails validation, ~~then~~ each component readMeter Reading of the 'meta-~~readread~~' is considered separately with the above validations.

~~NB~~

Note: the ~~Forward~~ Estimate Test and the ~~data stream~~ Datastream Inactive Test are performed against existing readsMeter Readings to determine whether ~~these existing reads~~ they are eligible for use in the start and end date tests. ~~MDPVersionDT~~ MDPVersionDT validation is still undertaken.

4.4 MSATS Data File Validations

All submitted 'Meter Data ~~Notification~~ Notification' data files must pass the following MSATS validations before they are accepted and loaded into ~~the MSATS system~~.

4.4.1 Interval Data

TABLE 9: INTERVAL DATA INFORMATION

Table 8 Interval Data Information

Term	Description
Submitting MDP	MDP is the <u>Current</u> MDP for the <u>readMeter Reading</u> date for that <i>NMI</i> in CATS. MDP is active in CATS.
NMI, NMI SUFFIX	<i>NMI</i> and <i>NMI</i> suffix must exist in CATS
Period (Readings)	48 numeric values within string (47 commas) String should contain no Alpha <u>alpha</u> characters (i.e. 0-9, <u>"-"</u> and <u>"."</u> only)
	No blank fields and no double commas
Status	Length of string is 48. String can only contain <u>"A"</u> <u>"A"</u> – Actuals, <u>"S"</u> <u>"S"</u> – Substitute, <u>"F"</u> <u>"F"</u> – Final Substitute and <u>"E"</u> <u>"E"</u> – Estimates.

Term	Description
Settlement Date	Valid date format
MDPVersionDT	Valid date format

4.4.2 Consumption Data

TABLE 10: CONSUMPTION DATA INFORMATION


Table 9 Consumption Data Information

Term	Description
Submitting MDP	MDP is the <u>Current</u> MDP for that <u>NMI</u> in CATS for <u>read</u> the <u>Meter Reading</u> period. <u>MDP is active in CATS.</u>
NMI, NMI SUFFIX	<u>NMI</u> and NMI suffix must exist in CATS
Reading	Only 1 value within string (0 commas) String should contain no <u>Alpha</u> characters (i.e. 0-9, <u>"/"</u> and <u>","</u> only)
Status	Length of String is 1. Can only contain <u>"A"</u> – Actuals, <u>"S"</u> – Substitute, <u>"F"</u> – Final Substitute and <u>"E"</u> – Estimates.
From Date	Must be in valid date format and be between <u>Start</u> date and <u>End Date</u> of the NMI Suffix in CATS.
To Date	Must be in valid data format and be between <u>Start</u> date and <u>End Date</u> of the NMI Suffix in CATS.
	No blank <u>reads</u> fields and no double commas
MDP Version Date	Valid date format


4.4.3 Consumption Meter Data Record date relationship examples

A. One existing metermetering data record loaded into MDM


The following examples assume that the data-streamDatastream is active for the entire period.




Scenarios in relation to Record Above



1. This record **will load**, - existing record archived to history.



2. This record **will load**, - existing record 1 archived to history. In this case start date of new record is before start date of existing record and the end date of new record is after the end date of the existing record.




3. This record **will not load** unless record 1 is a forward estimate. In this case the start date of new record is after the start date of the existing record and therefore will fail the validation.









4. This record **will not load** unless record 1 is a forward estimate. In this example the start date of the new record is after the start date of existing record, the end date of the new record is before end date of existing record, and therefore will fail the validation.

B. Three existing ~~meter~~metering data records loaded into MDM

The following examples assume that the ~~data-stream~~Datastream is active for the entire period.



Scenarios in relation to Records Above



5. This record **will not load** unless record 2 is a forward estimate; - there is no date continuity to record 3. Data gap would result 21/2/02 – 1/3/02

6. This record **will only load** if record 3 is a forward estimate (Record 3's read_type_flag = 'E'). If record 3 is forward estimate, then new record replaces previous records 1,2 and 3.

7. This record **will load**, - replaces previous records 1, 2 and 3.

8. This record **will not load** unless record 1 is a forward estimate; - there is no date alignment with Record 1. Data gap would result 26/1/02 – 1/2/02

9. These records **will load**. If the meta-read validation fails, then each record of the meta-read will be validated separately – these 2 will fail as they do not align with existing records (unless record 1 is a forward estimate – then both records will load).


10. This record **will load**, - replaces previous record 1, if the version date is greater than existing record.

11. All of these records **will load**. New records will replace existing records 1,2 and 3. If the meta-read validation fails, then each record of the meta-read will be validated separately – record 1 will load if it passes the MDPVersionDT test, records 2 and 3 will fail as they do not align with existing records (unless records 2 & 3 are forward estimates).


12. This record **will NOT load** unless record 1 is a forward-estimate an Estimate – there is no start date alignment with record 1

|


C. Overlapping ~~reads~~Meter Readings in a transaction




Scenarios in relation to Existing Records Above



13. This record **will NOT load** unless record 2 is a forward estimate – there is no data continuity to replace record 2.
Data gap would result 26/2/02 – 1/3/02.




14. This first record **will only load** if record 3 is a forward estimate (read_type_flag = 'E') and its MDPVersionDT is greater than the max of MDPVersionDT of the first 2 existing records. Record 2 will **not** load as it is a duplicate record in the file, (see 3.1 Principles).




15. The first record **will load**, and the second record **will not load**, unless the first new read is a forward estimate and has an MDP Version ID that is less than the second record. Start and end dates are INCLUSIVE, meaning that the start of a subsequent record must be 1 day after the end date of the previous record.

D. One existing ~~meter~~metering data record loaded into MDM (example 1)


The following examples assume that the ~~data-stream~~Datastream is not active for the entire period.



Scenarios in relation to Records Above




16. This record **will not load**, - as ~~data-stream~~Datastream is not active at end date.



17. This record **will not load**, - as it spans period where ~~data-stream~~Datastream is not active (~~data-stream~~Datastream not active at start date of record).

E. One existing ~~meter~~metering data record loaded into MDM (example 2)

The following examples assume that the ~~data-stream~~Datastream is not active for the entire period.




Existing Active Data Stream Records in CATS (ie: inactive 2/2 to 1/3)


Existing Meter Data Records in MDM

New Meter Data Records to MDM


Scenarios in relation to Records Above




18. This record **will not load**, - as it spans period where ~~data-stream~~Datastream is not active




19. This record **will load** if the existing record is a ~~forward-estimate~~an Estimate (read_type_flag = 'E').




20. These 2 records **will load**. New records will replace the existing record. If the 'meta-read ~~validation~~validation' fails, ~~then~~ the individual records of the 'meta-read~~read~~' will be validated separately - records **will not load** as they do not align with existing ~~meter~~ record.




21. This record **will load**, - replaces existing record 1 if the version date is greater than existing record.




22. This record **will load** - as new record does not overlap any existing record. There will be a gap in the ~~meter~~metering data for period where ~~data-stream~~Datastream is inactive and also up to 6/3/02.



23. This record **will not load** unless record 1 is a ~~forward-estimate~~an Estimate as new record does not align with the start date of the existing record.



24. This record **will not load** unless record 1 is a ~~forward~~an estimate as new record does not align with the start date of the existing record.




25. This record **will not load** - spans period where ~~data-stream~~Datastream is inactive

05/02/02 25/03/02

26. This record **will not load** – spans period where ~~data stream~~DataStream is inactive.

F. One existing ~~meter~~ metering data record loaded into MDM which ~~that~~ now spans period of inactive ~~data-stream~~ Datastream


The following examples assume that the ~~data-stream~~ Datastream is not active for the entire period.




Scenarios in relation to Records Above




27. This record **will not load**, - as ~~data-stream~~ Datastream is not active at end date.




28. This record **will not load**, - as it spans period where ~~data-stream~~ Datastream is not active



29. This record **will load**, existing record spanning 1/1 to 26/6 archived to history table.



30. This record **will load** - existing record is not validated against as it is an invalid record (spans period where ~~data-stream~~ Datastream is inactive).



31. This record **will load**, existing record spanning 1/1 to 26/6 archived to history table. Existing record not validated against since existing read is invalid.




32. Both Records **will load** even though gap exists between 25/1 and 1/2; existing record spanning 1/1 to 26/6 archived to history table. In the future may be different MDPs for these two active ~~data-stream~~ Datastream periods. Existing read is invalid so it is NOT validated against




33. Both these records **will load**. Existing record spanning 1/1 to 26/06 archived to history table.

G. One existing ~~meter~~metering data record loaded into MDM which now spans period of inactive ~~data stream~~Datastream

The following examples assume that the ~~data stream~~Datastream is now not active for the entire period, but has no gaps.



Scenarios in relation to Records Above



34. This record **will not load**, - as ~~data stream~~Datastream is not active at start or end date.




35. This record **will load**, - existing record spanning 1/1 to 26/6 archived to history table. Existing read is invalid so it is NOT validated against.


H. **Data load in first period of active ~~data-stream~~Datastream where existing ~~meter~~metering data record loaded into MDM for second period of active ~~data-stream~~Datastream**

The following examples assume that the ~~data-stream~~Datastream is not active for the entire period.


Example 1: _____



Scenarios in relation to Records Above




Example 2: _____



Scenarios in relation to Record Above






39. First record **will load**. Second record **will NOT** ad load as data stream is inactive at the reading end date.


40. This record **will not load** unless the existing readMeter Reading is a forwardan estimate. New record start date does not align with overlapping existing record

I. **Data load in first period of active ~~data-stream~~Datastream where no existing ~~meter~~metering ~~data~~ record loaded into MDM**


The following examples assume that the ~~data-stream~~Datastream is not active for the entire period.



Scenarios in relation to Records Above




41. This record **will load**.




42. The first record **will load**. The second record **will not load** as the ~~data~~streamDatastream is not active at the end

J. Three existing ~~meter~~metering data records loaded into MDM


The following examples assume that the ~~data-stream~~DataStream is active for the entire period.




Scenarios in relation to Records Above




43. This record **will load**. The three existing records will be archived to history. As start date and end date of new record does not overlap any existing records, there is no requirement for alignment of dates.



44. This record **will load**. The three existing records will be archived to history. As new record start date overlaps first existing record, there is a requirement for alignment of start dates.




45. This record **will only load** if record 3 is a forward estimate as the end date of the new record overlaps existing record 3 (forward estimate means read_type_flag = 'E'). If record 3 is a forward estimate, then new record replaces previous records 1, 2 and 3.




46. This record **will not load** unless Record1 is a forward estimate, as the new record does not align with start date of overlapping first existing record.

K. No existing ~~meter~~metering data records loaded into MDM

The following examples assume that the ~~data-stream~~Datastream is active for the entire period.



Note: all of the following records are in the one ~~meter~~metering data file.



47. Records 1, 3, and 5, 6 and 7 **will load**. Records 2 and 4 will fail as they do not align with the previous loaded record.


One Meta read is created (records 5, 6 & 7) – other read records will be processed on a record by record basis.

Record 6 03/08/02 02/09/02


Record 7 03/09/02 02/10/02

L. Existing ~~meter~~ metering data records loaded into MDM

The following examples assume that the ~~data-stream~~ Datastream is active for the entire period.




Note: Existing records are not ~~forward estimates~~ Estimates




48. Record **will load**.



49. Both records **will load**. Data gap still exists between 2/4/02 and 31/7/02.



50. Record **will not load**. New record does not align with existing record, and record 1 is not ~~a forward estimate~~ an Estimate.



51. Record **will load**. Data gap still exists between 2/2/02 and 28/2/02, and 2/4/02 and 31/7/02.

5. MSATS ERROR CODES (MDM)

All submitted Meter Data Notification data files that do not pass MSATS validations prior to data load will create an error. See the ~~CATS~~ Hints and Tips – [CATS & NMI Discovery](#) for more detail on the common error codes ~~found on the AEMO web site~~.

5.1 Validation Failure Error Codes (MDM)

All error codes relating to validation failures of MDM ~~meter~~metering data files are tabulated in MSATS. This listing is located under Administration > Codes Maintenance > Error Codes.

Appendix A. GLOSSARY

Terms which are defined in the National Electricity Rules are deemed to have the same meaning under these Procedures. See also the MSATS Procedures for further definition of terms.

Table 11: GLOSSARY

Term	Description
ase-XML	A Standard for Energy eXtensible Markup Language
CATS	The Consumer Administration and Transfer Solution.
Data-stream	A stream of metering data associated with a connection point, as represented by a NMI. A NMI can have multiple data streams (from multiple meters or from multiple channels or registers that comprise a single meter). Each data stream is identified by a suffix which is associated with the NMI to which it belongs.
DCTC	Data Collection Type Code (refer R25 Schema changes)
Interval-meter	Is a meter that is capable of providing energy data for Trading Intervals (see National Electricity Rules). Classified in MSATS as COMMS 1 to 4, MRIM or UMCP.
MDM	The part of the MSATS system which is known as 'meter data management'.
MDM data stream	The term used to represent a NMI suffix, as distinct from a meter suffix. The NMI suffix is required by MDM to enable the metering data associated with a NMI to be correctly identified.
MDP	See Metering Data Provider
Metering Data Provider (MDP)	The person responsible for the collection, processing and transfer of energy data from the meter or data logger to AEMO. The MDP consists of two accredited service provider groups: The Metering Data Agent, who is responsible for the type 1, type 2, type 3 and type 4 metering installations; and The Metering Provider Category D, who is responsible for the type 5, type 6 and type 7 metering installations.
MSATS	The Market Settlements and Transfer Solution
MSATS system	The centralised computer system which is managed by AEMO for MSATS.
National Electricity Rules	The legal instrument formed under the National Electricity Law. The National Electricity Rules is available from AEMC.
AEMO	Australian Energy Market Operator Limited as defined in the National Electricity Rules.
NMI	National Metering Identifier as defined in the National Electricity Rules.
Profile-name	Is the code that identifies the algorithmically derived shape of consumption that will be used to determine trading intervals for Basic Meter readings?
SAMPLE	The NMI classification code which is used to define a metering installation that forms part of the sample of metering data for use in a non-NSLP profile shape application.
TNI	Transmission Node identifier means the unique identifier assigned by AEMO to each node in the transmission system.